

The SubliJet, ArTainium and ChromaBlast QuickConnect Bulk Ink Systems for the Epson C120/C110/D120 printer contain a cartridge with five individual dampers that is used in place of the individual OEM (Epson) cartridges. This bulk ink system cartridge has a single chip that periodically needs to be reset so that the printer can continue to use ink from the bulk ink system. The frequency of this reset action will depend upon the number of images that are printed and the printer settings.

The following are simple instructions for resetting the bulk ink system.


Once the printer 'recognizes' that the ink levels have reached a certain level it will cease to print and the **orange** ink-out light will start to flash.

Press the **ink-out** button until the ink carriage moves into the far right position. The ink carriage will come to rest in the carriage bay area.

Press the **white reset button** at the top of the bulk ink system ink cartridge.

Again, Press the **ink out** button on the front of the printer.

The printer will begin to reset and recharge. After the printer has completed the resetting activity, the **orange** light will turn off. At this point the bulk ink system has been successfully reset and the printer is again ready for use.



Note:
If the reset process described does not reset your bulk ink system, please contact Technical Support at **888-253-1679** or **e-mail support@sawgrassink.com**